

Quantec Interface Unit c/w Remote Socket

Part No. OT636



Overview

- Allows any device with a normally open or normally closed 6.35mm (1/4 inch) jack plug to be connected to Quantec.
- Particularly suited for use with our NC805MD Portable Movement Detector (n/o operation), QT644 Floor Pressure mat (n/o operation), QT633 Bed Exit mat (n/c operation) or QT634 Chair Exit Mat (n/c operation).
- Must be wired as a slave to a QT602 or QT609 range addressable call point or QT630 dementia care controller.
- When the device connected to the QT636 is operated a call will be generated on the Quantec call system as programmed.
- Mounts on a standard UK 25mm single gang back box.

More Information

Technical Specifications

1mA. Quiescent current Alarm current

N-; N+; L+; SW. Wired as a slave to a QT602 call point, QT609 call point or QT630 dementia care Connections

controller.

Onboard 6.35mm Remote Jack Socket Yes, can be configured to accept a n/o or n/c jack plug.

Onboard Sounder No, Onboard Infrared Receiver No.

87~W~x~87~H~x~33~D~mm. Can be mounted on a standard UK 25mm single gang flush or surface back Product dimensions (mm)

Construction & finish Plastic. IP20. 68g



IP Rating

T 01942 322744

E sales@c-tec.co.uk

W www.c-tec.com



















Operating conditions/temperature -5° C to $+40^{\circ}$ C. Max relative humidity: 95%.

















